


**M** LEVELO



**Levelo**

**CARTES Card Tracker**

SKU: LVLCFMCTTR

# Features

Features	2
Specifications	3
App Instructions	3
1. Turning on the Device	3
2. Pairing the Device	3
3. Enabling Lost Mode	5
4. Removing the Device	6
5. Re-Pairing	6
Function Introduction	6
Instructions for Use	7
FAQ	8
Disposal Information	9
Safety Precautions	10
Disclaimer	11
Warranty	12
Contact Us	12

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

## **Features**

- 1.** Provides the last known location of your item on a map, even when you're not within Bluetooth range.
- 2.** Emits a loud sound to help you quickly locate your item when you're close by.
- 3.** Activates enhanced security measures to prevent unauthorized access and alerts you if your item is moved.
- 4.** Receive a notification when your item moves beyond a predefined distance from you.
- 5.** Offers a wider search radius than standard Bluetooth trackers, increasing the chances of finding your item.
- 6.** Monitors for unusual tracking patterns and notifies you if the tracker might be used to follow your movements surreptitiously.
- 7.** Features a practical hook for easy attachment to your belongings, enhancing portability and security.
- 8.** Ideal for securing valuable personal items like wallets, passports, and electronics.
- 9.** Integrates seamlessly with the Find My app, utilizing the network of devices to locate items.
- 10.** Enables you to pinpoint your lost item's location nearby using the app on your phone.
- 11.** Utilizes the app to show the location of your item on a map and guides you to its vicinity when it's beyond Bluetooth range.
- 12.** Supports convenient wireless charging and recommends charging every three months to maintain battery health.


## Specifications

Model Name	Cartes
Brand Name	Levelo
Wireless Charging	5W
Thickness	1.5 mm
Operating Temperature	-20°C to +70°C
Battery	3V 100mAh
Compatibility	Compatible with Apple Find My and Siri
Bluetooth Name	Cartes

## App Instructions

### 1. Turning on the Device

Press and hold the button for 5 seconds. The device will beep to indicate it has turned on.




### 2. Pairing the Device

Before initiating the pairing procedure, ensure Bluetooth is enabled on your phone.

**2.1** Launch the app.

**2.2** Tap the "Items" tab at the bottom of the screen, then select "Add Item."

**2.3** Choose "Other Supported Item" to continue with the pairing process.




**2.4** A pop-up will appear saying "Searching Items."

**2.5** Ensure your Item Locator is close to your phone. Wait until you see "Cartes" then tap "Connect."




**2.6** Follow the prompts to add a name and select an emoji for your connected item, then click "Continue."



**2.7** When "This Item Is Linked to Your Apple ID" appears, tap "Agree."

**2.8** Click "Finish" to complete your item setup.



### **3. Enabling Lost Mode**

**3.1** Launch the Find My app and navigate to the "Items" tab, then select your item.

**3.2** Tap "Enable" under the Lost Mode section.

**3.3** Read the instructions, tap "Continue," and provide a phone number or email address.

**3.4** Confirm the contact information, personalize the lost message, and tap "Activate" to finalize the setup.

## **4. Removing the Device**

**4.1** Launch the app and navigate to the "Items" tab, then select your item.

**4.2** Tap "Remove Item" and then confirm by tapping "Remove" to complete the operation.

## **5. Re-Pairing**

**5.1** After removing the device in the app, it will beep and the light will flash six times.

**5.2** The device will not shut down but will enter pairing mode.

**5.3** If the device is not re-paired within 10 minutes, it will exit the pairing state, and pairing with the app will not be possible.

**5.4** To re-pair the device, press the device button once. The device will emit a sound and the light will flash once, indicating it has re-entered the pairing state and can be paired with the app again.

# **Function Introduction**

## **1. Locate Your Item**

If your missing item isn't nearby, the Find My app can still assist in tracking it down via the Find My network—encompassing hundreds of millions of iPhone, iPad, and Mac devices globally. Nearby devices securely relay the location of your missing device to iCloud, allowing you to view its position within the Find My app. This process is entirely anonymous and encrypted to ensure everyone's privacy.



## 2. Play Sound

Open the Find My app and navigate to the 'Items' tab, then select your item. Click on 'Play Sound,' and the device will emit a beep, facilitating an easy location of the item.

# Instructions for Use

## 1. Power On

- 1.1 Press and hold the button for five seconds to turn on the device.
- 1.2 The device will emit a beep, and the light will flash three times, indicating that the device is now on.

## 2. Device Status Confirmation

- 2.1 To check if the device is working, double-click the device button.
- 2.2 The device will emit a beep, and the light will flash three times.
- 2.3 If there is no beep, the device is turned off.
- 2.4 Press and hold the button for five seconds to power it on.

## 3. Re-enter Pairing Mode

- 3.1 After removing the device from the app, activate it again to enter pairing mode by pressing the device button once.
- 3.2 The device will emit a beep, and the light will flash six times.
- 3.3 The device will not shut down during this process.

**Note:** If the device is not re-paired within 10 minutes, it will exit pairing mode.

- 3.4 To initiate pairing at this point, press the device button once—the device will beep and the light will flash once, indicating it has re-entered pairing mode and is ready to be paired with the app again.

## 4. Factory Reset

- 4.1 Remove the item from the Find My app.



**4.2** After ensuring the device is powered on, double-click the device button. It will emit a beep.

**4.3** Press and hold the device button for eight seconds until the device beeps and the light flashes three times.

**4.4** Release the button to complete the factory reset. The device is now ready to be paired again.

## **5. Power Off**

**5.1** To turn off the device, press the device button five times within two seconds while the device is on.

**5.2** The device will emit a beep, the light will flash three times, and the device will be powered off.

## **FAQ**

### **1. When can the device be located?**

The device can be located when it is separated from its owner for an extended period. It becomes detectable by other Apple devices within the Find My network, allowing the owner to begin retrieving the device's location.

### **2. How to confirm whether the device has been turned on?**

To verify if the device is on, double-click the device button. The device will emit a beep, and the light will flash three times, indicating that it is operational. If there is no sound, the device is off. Press and hold the button for five seconds to power it on.

### **3. How is the device designed to discourage unwanted tracking?**

**A.** To prevent unwanted tracking, any Find My network accessory that is separated from its owner and moves with you over time will trigger a notification. If you possess an iPhone, iPad, or iPod touch, Find My will

send a notification to your Apple device. This feature requires iOS or iPadOS 14.5 or later.

**B.** If you don't have an iOS device or a smartphone: If a Find My network accessory is separated from its owner for an extended period, it will emit a sound when moved. These features are specifically designed to deter unauthorized tracking attempts without your consent.

#### **4. How is my privacy protected?**

Only you can see where your item is located. The location data and history are never stored on the item itself. Devices that relay the location of your item remain anonymous, and the location data is encrypted throughout the entire process. Consequently, not even Apple or our company can access the location of your device or identify the device that facilitates its discovery.

#### **5. What is the Find My network? And how does it work?**

The Apple Find My network offers a straightforward and secure method for locating compatible personal items. Utilize the Find My app on your iPhone, iPad, iPod touch, Mac, or the Find Items app on Apple Watch to map your items. Simply sync your compatible product with the Apple Find My app to see its location alongside your Apple devices. If your item goes missing, you can activate Lost Mode to display a message and contact details for anyone who might discover it. The Find My network is encrypted and maintains anonymity, ensuring that no one, including Apple or our company, can access the location of your item.

## **Disposal Information**

According to local laws and European Union disposal regulations, your product and/or its battery must be disposed of separately from household waste. Upon reaching the end of its lifecycle, you should transport it

to a collection point designated by local authorities. The separation and recycling of your product and/or its battery at the point of disposal aids in conserving natural resources and ensures that it is recycled in a manner that safeguards both human health and the environment.

## Safety Precautions


**1.** Do not use the device if the battery compartment is not secure. Examine devices to ensure that the battery compartment is securely fastened, e.g., that screws or other mechanical fasteners are tightened. Do not use the device if the compartment is not secure.

**2. WARNING:** Swallowing a battery can cause serious injury or death within as little as 2 hours, due to chemical burns and potential perforation of the esophagus.

If you suspect your child has swallowed or inserted a button battery, **IMMEDIATELY** contact the poisons information center or reach out to your country's emergency department.

**3.** Dispose of used button batteries promptly and safely, as even flat batteries can be dangerous.


**4.** Do not recharge, disassemble, expose to extreme temperatures (below  $-20^{\circ}\text{C}$  or above  $+70^{\circ}\text{C}$ ), or incinerate the battery to avoid the risk of fire and burns.



## Disclaimer

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are the trademarks of Apple inc, registered in the U.S. and other countries OS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. Use of the 'Works with Apple' badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple's 'Find My' network product specifications and requirements. Apple is not responsible for the operation of this device or its use, nor for its compliance with safety and regulatory standards.

To use the 'Apple Find My' app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended.



## **Warranty**

Products procured directly from the **Levelo** website or physical store comes with a 24-month warranty.

**Levelo** products purchased from any of our authorized dealers are guaranteed with a one-year warranty. If you wish to extend this warranty, you'll need to go to our website at **<https://levelobrand.com/warranty>** and fill out the necessary form, making sure to include your personal information and a photo of the product. After your request has been evaluated and accepted, we'll send you an email notification to affirm the extension of your product's warranty.

For more info, please check:

**Website: <https://www.levelobrand.com/warranty>**

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at: **[Info@levelobrand.com](mailto:Info@levelobrand.com)**

**Website: <https://www.levelobrand.com/>**

**Email: [Info@levelobrand.com](mailto:Info@levelobrand.com)**

**Instagram: [levelobrand](#)**

**Facebook: [levelobrand](#)**